



Air connections are located on both sides and can be exchanged according to mounting requirements. Only one connection is necessary for function.

- ① MKR Series: Air filter
MKRS Series: M5 port (air connection)
- ② MKR Series: M5 port (air connection)
MKRS Series: Air filter
- ③ Mounting of spring unit at MKS is omitted at MK.

Size [mm]	Item number	Holding power [N] MKR	Holding power [N] MKRS	A [mm]	A1 [mm]	A2 [mm]	A3 [mm]	B [mm]	B1 [mm]	B2 [mm]	B3 [mm]	B4 [mm]	X [mm]	G	H [mm]	Ø [mm]
12	MKR/MKRS 1200 A	650	350	51	15	5	31	56	37	15	11	18	18	M5	6	16
16	MKR/MKRS 1600 A	650	400	55	15	5	35	58	39	15	12,5	22	22	M5	6	16
20	MKR/MKRS 2000 A	1000	600	66	45	5	43	60	38	18	13	25	25	M8	10	20
25	MKR/MKRS 2500 A	1200	750	77	60	5	51	63	43	20	15	30	30	M10	12	22
30	MKR/MKRS 3000 A	1750	1050	92	68	5	60	77,5	48,5	25	14	34	35	M10	13	25
40	MKR/MKRS 4000 A	2250	1450	120	90	5	78,8	82	49	26	14	45	45	M10	15	30
50	MKR/MKRS 5000 A	3000	2000	132	108	5	90,8	82	49	30	9,5	50	50	M10	15	30
60	MKR/MKRS 6000 A	3000	2000	142	108	5	100,8	82	49	30	9,5	50	50	M10	15	30